

# X-G

## XBAN-G Setup Instructions



Top Arms



Center Pole

Tripod Base



Clamping Lever

1. Banner size can be anywhere from 24" to 36" wide and from 54" to 74" tall.

2. Place a grommet in each corner.

3. Pull Top Arms up, and slide Center Pole up from from the Tripod Base.

4. Attach the top grommets of the banner to both Top Arm Hooks.

5. Continue sliding Center Pole up until the banner bottom is 2" above the Bottom Hooks.

6. Push the Clamping Lever at the top of the Tripod Base to either side. This locks the Center Pole in place.

7. Attach bottom grommets to the Bottom Hooks.

There should be tension on the banner pulling it tight and bending the Top Arms forward. Adjust the Center Pole to achieve the correct tension.



Clamping Lever