BANNER SIZE:
31" to 33" wide by 54" to 80" tall

Arms

Leg

Hub

Base

1. Banner must have a grommet in each corner and fall within the size range listed above.

2. Plug the bottom of the Leg into the Base and tighten the thumbscrew.

3. Plug the 4 Arms into the Hub.

4. Hang the top grommets of the banner onto the Hooks at the top of the Arms.

5. Pull down the banner and hook the bottom grommets onto the Hooks on the Legs.